

CRF/XR50

SHOCK SPRING INSTALLATION INSTRUCTIONS

Thank you for the purchase of this new BBR Shock Spring! Every effort has been made to develop the highest quality products possible.



Install

1. Slide the bottoming bumper up.
2. Loosen the 14mm nut.
3. Unscrew the aluminum shock end.
4. Remove the stock spring.
5. Install the BBR Spring and reassemble

BBR

MOTORSPORTS (253) 631-8233 · www.bbrrmotorsports.com



CRF/XR50

SHOCK SPRING INSTALLATION INSTRUCTIONS

Thank you for the purchase of this new BBR Shock Spring! Every effort has been made to develop the highest quality products possible.



Install

1. Slide the bottoming bumper up.
2. Loosen the 14mm nut.
3. Unscrew the aluminum shock end.
4. Remove the stock spring.
5. Install the BBR Spring and reassemble

BBR

MOTORSPORTS (253) 631-8233 · www.bbrrmotorsports.com



CRF/XR50

SHOCK SPRING INSTALLATION INSTRUCTIONS

Thank you for the purchase of this new BBR Shock Spring! Every effort has been made to develop the highest quality products possible.



Install

1. Slide the bottoming bumper up.
2. Loosen the 14mm nut.
3. Unscrew the aluminum shock end.
4. Remove the stock spring.
5. Install the BBR Spring and reassemble

BBR

MOTORSPORTS (253) 631-8233 · www.bbrrmotorsports.com



CRF/XR50

SHOCK SPRING INSTALLATION INSTRUCTIONS

Thank you for the purchase of this new BBR Shock Spring! Every effort has been made to develop the highest quality products possible.



Install

1. Slide the bottoming bumper up.
2. Loosen the 14mm nut.
3. Unscrew the aluminum shock end.
4. Remove the stock spring.
5. Install the BBR Spring and reassemble

BBR

MOTORSPORTS (253) 631-8233 · www.bbrrmotorsports.com

